

Welcome to your Smart Bell

Training can be rewarding and a lot of fun. Be patient and remember that consistency and positive reinforcement are the keys to learning the desired behavior.



Installation:

****Note:** This is a self-powered doorbell. There is no battery in the activator (1).

1. Test the doorbell by plugging the receiver (2) into the wall and pressing the activator (1).

**** Note:** If your dog is sensitive to sound, do not test with the receiver close to him or her.

2. Apply the included double-sided adhesive to the back surface of the activator (1).

3. Select the desired location for the activator (near or on the door where your dog exits to go potty). We recommend a height of 20 inches but higher or lower is ok based on the height of your dog.

4. Clean the selected surface and paste the activator in place.

**** Note:** If you wish to mount directly to dry wall the included adhesive may cause damage to the surface. Wood or glass surface is preferable. If mounting to dry wall use 3M command strips.

5. Plug the doorbell receiver into the wall outlet.

6. Select your melody (38 tone options) by pressing the bottom button (5) on the receiver (2).

7. Select your volume level by pressing the top button (4) on the receiver (4 volume level options)

Training:

1. Choose a Location:

Place the Mighty Paw Smart Bell on, or near, the door where your dog exits to go "potty". Keep in mind that dogs typically use their nose to ring the bell once trained.

2. Form a Connection:

Introduction: First the dog must learn to engage with the button (activator). Do this by pointing to and pressing the activator using a term like "push the button". You can use peanut butter or other dog safe spread if your dog is hesitant to engage with the bell. Now encourage your dog to "push the button". Praise and reward your dog with treats for activating the doorbell. Repeat this step for a few days.

****Note:** if your dog is sensitive to noise you can acclimate him or her by placing the receiver in another room and gradually bringing it closer.

Connection: Now that your dog is acclimated to "pushing the button" each time you let your dog out to go to the bathroom, reach down, touch the bell (or have them touch the bell), and use a phrase such as "go potty". Immediately let your dog out. Repeat this each time until your dog connects ringing the bell with being let out to go to the bathroom.

3. Reinforce with Praise:

Praise and/or give a treat only when "potty time" was a success. Your dog should associate the doorbell with potty time only. Consistency is key! Do not reward your dog for ringing the bell only to play outside.

Troubleshooting: Please visit mightypaw.com/FAQ for frequently asked questions and troubleshooting
To sync or re-sync your Smart Bell: With the receiver plugged-in hold either key on the side for 3 seconds. The LED will flash on/off. This is now in sync mode. Touch the activator(s) to re-sync. Test it.

THANKS FOR ORDERING

from

MIGHTYPAW

NOW GO HAVE SOME FUN!

TO REGISTER YOUR FREE
90 DAY WARRANTY VISIT
mightypaw.com/smartbell

info@mightypaw.com • mightypaw.com

INSTALLATION AND TRAINING

SMART BELL

BY MIGHTYPAW

DOG POTTY TRAINING DOORBELL



info@mightypaw.com • mightypaw.com